



INSTRUCTIONS FOR USE

4XXX Series Skyloc™ Self Retracting Lifelines

Complies with the current ANSI Z359.1-2007 and all applicable OSHA regulations and requirements.

Reliance Industries
P.O. Box 2046
Deer Park, TX 77536

Phone : 281-930-8000
Toll Free : 888-362-2826
Fax : 281-930-8666

Contents

| | |
|--|----------------|
| DESCRIPTION | 4 - 5 |
| PRODUCT SPECIFICATIONS | 6 |
| APPLICATION | 7 |
| A. PURPOSE | 7 |
| 1) PERSONAL FALL ARREST | 7 |
| B. USE LIMITATIONS | 7 |
| 1) CAPACITY | 7 |
| 2) FREE FALL | 7 |
| 3) FALL CLEARANCE | 7 - 8 |
| 4) SWING PENDULUM FALLS | 9 - 11 |
| 5) CHEMICAL HAZARDS | 11 |
| 6) HEAT | 11 |
| 7) CORROSION | 11 |
| 8) ELECTRICAL HAZARDS | 12 |
| 9) MOVING MACHINERY | 12 |
| 10) SHARP EDGES AND ABRASIVE SURFACES | 12 |
| 11) WEAR AND DETERIORATION | 12 |
| 12) IMPACT FORCES | 12 |
| SYSTEMS REQUIREMENTS | 12 |
| A. COMPATIBILITY OF SYSTEM PARTS | 12 |
| 1) COMPATIBILITY OF COMPONENTS AND SUBSYSTEMS | 12 |
| 2) COMPATIBILITY OF CONNECTORS | 13 |
| 3) ANCHORAGES AND ANCHORAGE CONNECTORS | 13 - 14 |
| INSTALLATION PROCEDURE | 14 |
| A. CONNECTING THE SRL TO AN ANCHOR POINT | 14 |
| B. CONNECTING THE SRL TO A HARNESS | 15 |
| C. PREPARATION FOR USE | 16 |
| D. INSPECT PRIOR TO USE | 16 |
| E. PLAN SCOPE OF WORK TO BE PERFORMED ANALYSIS) | 16 - 18 |
| CARE OF THE LANYARD | 18 |
| INSPECTIONS | 19 |
| A. INSPECTION FREQUENCY | 19 |
| B. INSPECTION PROCEDURE | 19 - 20 |
| TRAINING | 20 |
| RESCUE PLANNING | 21 |
| SERVICING | 21 |
| GUARDING AGAINST APPLICATION FAILURE | 21 - 22 |
| WARNINGS AND LIMITATIONS | 22 - 23 |
| LABELING | 23 - 25 |
| INSPECTION RECORD | 26 |
| PART NUMBER LIST | 27 |
| WARRANTY STATEMENT | 27 |

Instructions for Use

User Instructions

Reliance Self Retracting Lifelines

User Instruction Manual - Self Retracting Lifelines

This manual is intended to meet the Manufacturer's Instructions as required by the current ANSI Z359.1(2007) ,and should used as part of an employee training program as required by OSHA.

WARNING: *This product is one part of a personal fall arrest, restraint, work positioning, personnel riding, climbing, or rescue system. Without the other necessary components in such sub-systems the self retracting lifeline itself serves no useful purpose. The user must follow the manufacturer's instructions for each component of the system. These instructions must be provided to the user before using this product and retained for ready reference by the user. The user must read, understand (or have explained), and heed all instructions, labels, markings and warnings supplied with this product and with those products intended for use in association with it before using this equipment. Manufacturer's instructions must be followed for proper use and maintenance of this equipment. National standards and state, provincial and federal laws require the user to be trained before using this product. This manual can be used as part of a such a user safety-training program that is appropriate for the user's occupation.*

IMPORTANT: *Alterations or misuse of this product or failure to follow instructions may result in serious injury or death. If you have questions on the use, care, or suitability of this equipment for your application, contact RELIANCE Fall Protection for information.*

DESCRIPTION

The Skyloc™ Self Retracting Lifeline (SRL) is designed to be a component in a personal fall arrest systems (PFAS). It may be used in most situations where a combination of worker mobility and fall protection is required (i.e. inspection work, general construction, maintenance work, oil production, confined space work, etc.). The Skyloc™ SRL is designed for use by a single person weighing 310 lbs [140.6kg] (body weight plus tools). Skyloc™ Self Retracting Lifeline features a cam-action pawl system ensuring positive lock-up even in the most demanding environments. Available standard cable / web lengths allow the Skyloc™ to be mounted overhead in areas where there are no other convenient anchor points for personal fall arrest means. The Pelican™ snaphook's unique hook body design prevents the accidental "false engagement" to the harness dorsal D-ring, while the case swivel or anchor connector (depending on model) provides an easy to see load indicator showing whether the Skyloc™ has been exposed to a fall arrest load and needs to be serviced.

Identifying Components of Skyloc™ Self Retracting Lifelines





Figure 1

4006, 4007, 4008, 4009, 4011

Instructions for Use



4015, 4020




Figure 3

4030, 4050, 4051, 4075, 4100, 4101, 4120, 4121, 4130, 4131

PRODUCT SPECIFICATIONS

| Part # | Working Length | Line Type | Weight | Hook Type | Housing Type | Housing Dimensions |
|--------|----------------|--------------------------|-----------------|-----------------------|-----------------------------|--|
| 4006 | 6' (1.8m) | 3/16" (4.5mm) galvanized | 5 lbs (2.2kg) | 3007 Swivel Zn Plate | Carbon Steel | 8"L X 4"W X 2"H (20cm X 10cm X 5 cm) |
| 4007 | 7' (2.1m) | 1" (25mm) polyester web | 5 lbs (2.2kg) | 3007 Swivel Zn Plate | Carbon Steel | 8"L X 4"W X 2"H (20cm X 10cm X 5 cm) |
| 4008 | 7' (2.1m) | 1" (25mm) polyester web | 5 lbs (2.2kg) | 3011 Rebar Zn Plate | Carbon Steel | 8"L X 4"W X 2"H (20cm X 10cm X 5 cm) |
| 4009 | 7' (2.1m) | 1" (25mm) polyester web | 5 lbs (2.2kg) | 3014 Tieback Zn Plate | Carbon Steel | 8"L X 4"W X 2"H (20cm X 10cm X 5 cm) |
| 4011 | 7' (2.1m) | 1" (25mm) polyester web | 6 lbs (2.7kg) | 3007 Swivel Zn Plate | Carbon Steel | 8"L X 4"W X 2"H (20cm X 10cm X 5 cm) |
| 4015 | 18' (5.5m) | 3/16" (4.5mm) galvanized | 7 lbs (3.1kg) | 3006 Pelican Zn Plate | LDPE overmolded ABS Plastic | 11"L X 6"W X 3"H (28cm X 15cm X 8cm) |
| 4020 | 20' (6.1m) | 1" (25mm) polyester web | 8 lbs (3.6kg) | 3006 Pelican Zn Plate | LDPE overmolded ABS Plastic | 11"L X 6"W X 3"H (28cm X 15cm X 8cm) |
| 4030 | 30' (9.1m) | 3/16" (4.5mm) galvanized | 25 lbs (11.3kg) | 3007 Swivel Zn Plate | Carbon Steel | 15"L X 9"W X 4"H (38cm X 23cm X 10cm) |
| 4031 | 30' (9.1m) | 3/16" (4.5mm) stainless | 25 lbs (11.3kg) | 3008 Swivel Stainless | Stainless Steel | 15"L X 9"W X 4"H (38cm X 23cm X 10cm) |
| 4050 | 50' (15.2m) | 3/16" (4.5mm) galvanized | 26 lbs (11.7kg) | 3007 Swivel Zn Plate | Carbon Steel | 15"L X 9"W X 4"H (38cm X 23cm X 10cm) |
| 4051 | 50' (15.2m) | 3/16" (4.5mm) stainless | 26 lbs (11.7kg) | 3008 Swivel Stainless | Stainless Steel | 15"L X 9"W X 4"H (38cm X 23cm X 10cm) |
| 4075 | 75' (22.8m) | 3/16" (4.5mm) galvanized | 48 lbs (21.7kg) | 3007 Swivel Zn Plate | Carbon Steel | 19"L X 13.5"W X 4.5"H (48cm X 34cm X 11cm) |
| 4100 | 100' (30.4m) | 3/16" (4.5mm) galvanized | 44 lbs (20kg) | 3007 Swivel Zn Plate | Carbon Steel | 19"L X 13.5"W X 4.5"H (48cm X 34cm X 11cm) |
| 4101 | 100' (30.4m) | 3/16" (4.5mm) stainless | 44 lbs (20kg) | 3008 Swivel Stainless | Stainless Steel | 19"L X 13.5"W X 4.5"H (48cm X 34cm X 11cm) |
| 4130 | 130' (39.6m) | 3/16" (4.5mm) galvanized | 48 lbs (21.7kg) | 3007 Swivel Zn Plate | Carbon Steel | 19"L X 13.5"W X 4.5"H (48cm X 34cm X 11cm) |
| 4131 | 130' (39.6m) | 3/16" (4.5mm) stainless | 48 lbs (21.7kg) | 3008 Swivel Stainless | Stainless Steel | 19"L X 13.5"W X 4.5"H (48cm X 34cm X 11cm) |

The following specifications apply to all Skyloc™ Self Retracting Lifelines :

- **Maximum Arrest Force (MAF) :** 900 lbs (4kN)
- **Maximum Arrest Distance :** 42" (1.07m)
- **Maximum Capacity :** 1 worker, with a maximum combined tool and body weight of no more than 310 lbs (140.6kg). Certain Models have capacity up to 440 lbs (200kg). Contact Reliance Industries if higher capacity models are needed.

SELF RETRACTING LIFELINE APPLICATION

A. PURPOSE:

RELIANCE Self Retracting Lifelines (SRL's) are used as one component in a personal fall arrest system (PFAS). The SRL's described in this manual meet, ANSI Z359.1 and OSHA requirements (except where noted). These instructions, and markings borne by the SRL's, fulfill the instruction and marking requirements of those standards and regulations. This equipment is specifically designed to dissipate fall energy and limit the fall arrest forces that are transferred to the body.

1) PERSONAL FALL ARREST:

The self retracting lifeline is used as a component of a personal fall arrest system. Personal fall arrest systems typically include a full body harness, a connecting subsystem (energy absorbing device such as a shock absorbing lanyard or self retracting lifeline) and an anchorage connector. Maximum arresting force must not exceed 900 lbs (4kN) for ANSI Z359.1-(07) and 1,800 lbs (8kN) for OSHA.

B. USE LIMITATIONS:

Consider the following application limitations before using this equipment:

1) CAPACITY:

These SRL's are designed for use by persons with a combined weight (clothing, tools, etc.) of no more than 310 lbs (140kg). Persons with muscular, skeletal, or other physical disorders should consult a physician before using. Pregnant women and minors must never use this equipment. Increasing age and diminished physical fitness may reduce a person's ability to withstand shock loads during fall arrest or prolonged suspension. Consult a physician if there is any question about a user's physical ability to safely use this product to arrest a fall or remain suspended.

2) FREE FALL:

Personal fall arrest systems used with this equipment should be mounted overhead in such a way as to eliminate the possibility of a free fall.

3) FALL CLEARANCE:

There must be sufficient clearance below the user to arrest a fall before the user strikes the ground or other obstruction. The clearance required is dependent on the following factors (see Figure 4 for reference):

- Elevation of anchorage
- Connecting subsystem length
- Deceleration distance
- Free fall distance
- Worker height
- Movement of harness attachment element

**Note : Product Exceptions*

4011 Skyloc™ Self Retracting Lifeline: *The 4011 SRL utilizes an external energy absorber integrated into the lifeline itself. This does not change fall clearance calculations for this unit.*

4009 Skyloc™ Self Retracting Lifeline with 3014 Tieback Hook: *When tying back on to the lifeline, point of tie back must be below the webbing impact indicator (see Figure 1).*

Using the 4006, 4007, 4008, 4009, or 4011 with a Man-Lift :

1. *If the unit DOES NOT employ an external shock absorber, then the user must connect the SRL directly to the harness (see 'Installation Procedures') to provide shock absorption in the event that the user falls over the hand rail.*

2. *If the unit DOES employ an external shock absorber, then the shock absorber end must be attached to the users back to provide shock absorption in the event that the user falls over the hand rail.*

Based on testing results, if a user does not have a shock absorbing device on their back (whether it be a unit with internal brakes or an external shock absorber), the arrest load is isolated at the hand rail and the user could be over loaded with no shock absorption.

3. *Do not extract an amount of lifeline from the SRL and 'clip it off' to prevent it from retracting back into the unit. Doing so will ensure that a free-fall occurs if the user falls out of the basket and over the handrail, and will prevent the SRL from functioning properly.*

CALCULATE THE FALL CLEARANCE!

- 1) Determine distance beneath walking/working surface to nearest lower level or obstruction : Minimum Required Clearance - MRC
- 2) Add the Activation Distance - Distance required for lifeline to activate - Activation Distance - AD = 12" (.3m)
- 3) Add the Deceleration Distance - DD. No more than 30" (.76m)
- 4) Add the Safety Factor: Safety Factor - SF. 1.5' to 3' (.4 to .9m)

$$AD + DD + SF < \text{ or } = MRC$$

Instructions for Use




Figure 4

4) SWING PENDULUM FALLS:

Swing falls occur when the anchorage point is not **DIRECTLY** above the point where a fall occurs. If the worker fall in such a situation, there is a possibility of a swing fall that may bring him into contact with objects below or to the side of him, possibly causing serious injury or death. These objects must be removed or the SRL and/or anchorage point be repositioned directly over the worker to help reduce the risk of a swing fall. A Competent Person or Qualified Engineer should always be consulted if there exists a possibility of a swing fall occurring. The worker must be trained to understand that the width of his allowable work area can never exceed the anchorage height of the retractable over his walking/working surface.

For example, if a worker in a building with 10 ft (3m) floors walks 20 ft (6m) away from his anchorage he could fall and strike the floor below before his fall would extract any cable from the SRL.




Figure 5

If an object is in his swing path (or that of the cable) a hazardous situation exists. Two factors become evident in this situation :

First, due to the swing fall, horizontal speed of the worker may be high enough to cause injury if an obstacle in the swing fall path is struck by either the user or the cable (web). The hazard increases as the initial (before fall) length of extended cable is increased and as the initial angle which the cable makes with the vertical is increased. In the extreme case where a user has extended 90 ft (27.4m) of cable at an angle of 30 degrees with the vertical, the user can theoretically develop a horizontal speed of about 19mph (30.5km/h). By comparison, if the user has extended 50 ft (15.2m) of cable at an angle of 15 degrees with the vertical, the user may develop a horizontal speed of about 7mph (11km/h). This situation is clearly more tolerable but it may still be dangerous if hazards such as rigid or sharp objects, electrical conductors, or powered equipment are in the swing fall path.

The second factor that comes into effect in a swing fall is that the total vertical fall distance of the user may be much greater than if the user had fallen entirely vertically without a swing fall path. This hazard

Instructions for Use

also increases as the initial (before fall) length of extended cable is increased and as the initial angle which the cable makes with the vertical is increased. For example, if the initial extended cable length is 10 ft (3m), the drop at the bottom of the pendulum swing would be 1.3 ft (.4m) This is in addition to the cable extension due to the devices internal shock absorption which may be as much as 3.3. ft (1m). The total vertical fall distance would then be as much as 4.6 ft (1.4m) If, however, 50 ft (15.2m) of cable is initially extended at a 30 degree angle with the vertical, then a drop at the pendulum bottom of 6.7 ft (2m) would result. In this example, adding the 3.3 ft (1m) of cable extension due to internal shock absorption of the device, the total vertical fall distance could be as much as 10 ft (3m).

Minimize swing falls by working as close to the anchorage point as possible (see Figure 5). Do not permit a swing fall if injury could occur. Swing falls will significantly increase the clearance required when a self-retracting lifeline or other variable length connecting subsystem is used.

5) CHEMICAL HAZARDS:

Acidic, alkaline, or other environments with harsh substances may damage the webbing (if equipped) and hardware elements of this SRL. Polyester webbing is more resistant to attack by acids, but is subject to degradation by alkaline or neutral pH environments. If working in a chemically aggressive environment, an SRL that uses a cable lifeline is generally recommended. When working in the presence of chemicals, more frequent inspection of the SRL is required.

6) HEAT:

Do not use SRL's that utilize a web lifeline in environments with temperatures greater than 185°F (85°C). Protect the lanyard when used near welding, metal cutting, or other heat producing activities. Sparks may damage the lanyard webbing and reduce its strength.

IMPORTANT: *When working with tools, materials, or in high temperature environments, ensure that associated fall protection equipment can withstand high temperatures, or provide protection for those items.*

7) CORROSION:

Do not expose the device to corrosive environments for prolonged periods. Organic substances and salt water are particularly corrosive to metal parts. When working in a corrosive environment more

frequent inspection, cleaning, and drying of the SRL is required. See *Care* and *Inspection* sections for cleaning and inspection details.

8) ELECTRICAL HAZARDS:

Use extreme caution when working near energized electrical sources. Metal hardware on the SRL, the lifeline itself, and on other components connected to it will conduct electric current. Maintain a safe working distance [preferably at least 10' (3m)] from electrical hazards.

9) MOVING MACHINERY:

When working near moving machinery parts (e.g. conveyors, rotating shafts, presses, etc.), make sure that loose equipment is secured. Maintain a safe working distance from machinery that could entangle clothing, the lifeline, the harness, or other components connected to it.

10) SHARP EDGES AND ABRASIVE SURFACES:

Do not expose web lifelines to sharp edges or abrasive surfaces that could cut, tear or abrade and weaken the fibers. If working around sharp edges and abrasive surfaces is unavoidable use heavy padding or other protective barriers to prevent direct contact.

11) WEAR AND DETERIORATION:

Any SRL which shows signs of excessive wear, deterioration or aging, must be removed from use and marked "UNUSABLE" until destroyed. **See detailed inspection procedures.**

12) IMPACT FORCES:

Any SRL that has been subjected to the forces of arresting a fall must be immediately removed from service and marked as "UNUSABLE" until recertified or replaced. RELIANCE SRL's have impact load indicators built into either the hooks or the anchorage component on top of the SRL that facilitate inspection for fall loading.

SYSTEMS REQUIREMENTS

A. COMPATIBILITY OF SYSTEM PARTS

1) COMPATIBILITY OF COMPONENTS AND SUBSYSTEMS:

RELIANCE SRL's are designed to be used with RELIANCE approved components and connecting subsystems. Use of the SRL with products made by others should be evaluated by a competent person to ensure compatibility of components and hardware. Connecting subsystems must be suitable for use in the application (e.g. fall

Instructions for Use

arrest or restraint). RELIANCE manufactures a line of connecting subsystems for most applications. Contact RELIANCE for further information. Refer to the manufacturer's instructions supplied with the component or connecting subsystem to determine suitability. Contact RELIANCE with any questions regarding compatibility of equipment used with the SRL.

2) COMPATIBILITY OF CONNECTORS

Connectors, such as D-rings, snap hooks, and carabiners, must be rated at 5,000 lb. (22 kN) minimum breaking strength and comply with ANSI Z359.1-2007. RELIANCE connectors meet these requirements. Connecting hardware must be compatible in size, shape, and strength. Non-compatible connectors may accidentally disengage ("rollout") or false engage. Always verify that the connecting snap hook or carabiner and the D-ring on the harness or anchorage connector is compatible. Some harness models have web loop connection points. Do not use snap hooks to connect to web loops unless the snap hook complies with ANSI Z359.1-2007. A self-locking carabiner may also be used to connect to a web loop. Ensure the carabiner cannot cross-gate load (load against the gate rather than along the backbone of the carabiner). Connecting subsystems (self retracting lifeline, lanyard, rope grab and lifeline, cable grab, etc.) must be suitable for your application.

EXAMPLES OF INAPPROPRIATE CONNECTIONS :

- A. To a D-ring to which another connector is attached
- B. In a manner that would result in a load on the gate.
- C. In a false engagement, where features that protrude from the snap hook or carabiner catch on the anchor and seem to be fully engaged to the anchor point. (Reliance has designed the width of the head and gates of Reliance snap hooks to prevent this issue in most D-rings.)
- D. To each other.
- E. Directly to webbing or rope lanyard or tie-back.
- F. To any object shaped such that the snap hook or carabiner will not close and lock, or that could cause roll-out should a fall occur.

3) ANCHORAGES AND ANCHORAGE CONNECTORS

Anchorage for personal fall arrest systems must have a strength

capable of supporting a static load, applied in directions permitted by the system, of at least: (a) 3,600 lb. (16 kN) when certification exists, or (b) 5,000 lb. (22.2 kN) in the absence of certification. When more than one personal fall arrest system is attached to an anchorage, the anchorage strengths set forth in (a) and (b) must be multiplied by the number of systems attached to the anchorage. This requirement is consistent with OSHA requirements under 29 CFR 1910 & 1926.

Anchorage connectors must be selected carefully. Eyebolts should not be used if they will be loaded at an angle to their axis, unless the loads fall within design parameters for such use. Weld-on lugs should not be less than 1/2 in (12.7mm) in width and should not be made of steel with less than 50,000-PSI yield strength. The proper stress areas and weld areas must be calculated to assure proper safety. If in question, consult Reliance Industries Engineering for proper design requirements.

INSTALLATION PROCEDURE

A. CONNECTING THE SRL TO AN ANCHOR POINT

NOTE: Approved fall protection must be worn during Skyloc[™] Self-Retracting Lifeline installation at all times. Do not use the SRL as a method of personal fall protection until the system has been completely installed, inspected, and approved for use by a Qualified Person.

1. Installation of the Skyloc[™] Self-Retracting Lifeline begins with the identification of a suitable anchor point. The anchor point must be capable of supporting a 3,600 lb (16kN) load where certification of load carrying ability exists, or 5,000 lb (22.2kN) where certification does not exist. NOTE: These strengths must be multiplied by the number of persons that will be connecting to the anchorage point at any one time.
2. Pass a large carabiner or bow shackle (or other Reliance approved connecting means) through the swivel eye or handle at the top of the Skyloc[™]. This carabiner or bow shackle must be rated with a minimum breaking strength of at least 5,000 lb (22.2kN) and must be used for connecting to only 1 SRL at a time.
3. Secure the bow shackle or carabiner to the anchor point. If using a bow shackle, verify that it is a safety shackle and that the nut of the shackle has been fully captured using a clevis pin or lock ring to prevent accidentally disengagement. When using a carabiner make sure that the gate has fully closed and rotated into a locked position.

Instructions for Use

B. CONNECTING THE SRL TO A HARNESS

All 400X series SRL's can be connected directly to the harness webbing at the back D-Ring location utilizing the 4007-65 Connector (Figure 6).

1. Remove clevis connector from top of SRL case. (Up to 2 units may be connected to the anchor loop of the 4007-65 adaptor bracket) Pass clevis(s) through the 4007-65 anchor loop and reinstall anchor pin through clevis and secure anchor pin with the supplied safety locking pin (Figure 7).
2. Open bail connector by turning the knurled knob 90 degrees and pulling the spring loaded pin back and allowing the locking pin to lock open.
3. Pull both webbing shoulder straps located at the back D-Ring away from the black back plaque. Pull enough slack to allow the insertion of the bail connector through the webbing. Both web straps must be captured by the bail connector (Figure 8).
4. Pass bail connector behind webbing and close locking pin by aligning locking pin with the hole in the bail connector (Figure 9).
5. Twist knurled knob to release the spring loaded pin. Ensure pin is fully inserted into the bail connector hole and locks against the center barrel (Figure 10).




Figure 6



Figure 10



Figure 7



Figure 8



Figure 9

C. PREPARATION FOR USE

1. Once the Skyloc™ has been secured into position, extract a few feet of cable slowly to verify that there is tension on the line and the retraction spring is functioning correctly.
2. Give the cable a quick, sharp tug causing the unit to lock-up proving that the braking mechanism is operating correctly. Slowly allow the cable to be retracted back into the unit under the power of the retraction spring.

CAUTION: The cable/web must always be released slowly and in a controlled manner when rewinding the cable back into the unit; it should never be fully released in an uncontrollable manner. Allowing the cable to retract in an uncontrolled fashion could cause damage to the Skyloc, the workplace, or other users in the area. Always use a tagline attached to the snaphook to help guide the wire rope back into the unit when it is installed too far overhead to reach directly; this will also help in pulling the snaphook down to the user for connection to his harness.

Removal is the opposite if installation.

Installation methods are not limited to bow shackles or carabiners. Custom brackets are available for permanent or specialized installations. Contact Reliance to help identify specific installation methods for your situation.

D. INSPECT PRIOR TO USE:

Before the use of this SRL, inspect the SRL and all components of the PFAS:

- 1) Inspect the SRL to verify that it is in serviceable condition. Examine every inch of the lanyard or cable for severe wear, cuts, burns, frayed edges, abrasion, or other damage. Examine stitching for any pulled, loose, or torn stitches. See Inspection section for details. *Do not use if inspection reveals an unsafe condition. Always err on the side of safety*

E. PLAN SCOPE OF WORK TO BE PERFORMED (JOB SAFETY TASK ANALYSIS)

Plan procedures to safely perform tasks when using any components

Instructions for Use

of a PFAS. Some considerations are listed below (see APPLICATIONS, item B. USE LIMITATIONS section for additional details);

- 1) Anchorage Selection. In addition to strength considerations, the anchorage should be rigged to prevent a fall onto the structure when considering 2) and 4) below.
- 2) Swing pendulum fall
- 3) Rough surfaces or unprotected sharp edges that could cut or abrade the equipment if unprotected.
- 4) Workplace geometry
 - a) Free fall distance - Personal fall arrest systems used with this equipment should be mounted overhead in such a way as to eliminate the possibility of a free fall.
 - b) Deceleration distance - Maximum 30 in (.76m)
 - c) Total fall distance - The sum of the activation distance and deceleration distance plus a safety margin.
 - d) A careful examination must be made of the workplace by a Competent Person before the selection or installation of Skyloc™ anchorage points. Consideration must be given both to the movement of materials (Will cranes be used to “fly” equipment or parts in?) and workers around the workplace to ensure that potentially hazardous situations are avoided.
 - e) Areas where overhead cranes or gantries are used must be examined to verify that neither the moving loads or lifting wires can interfere or snag the extended wire rope / web of a Skyloc™ SRL causing a worker to be dislodged.
 - f) Overhead lighting and electrical cables must also be identified to insure that installation of the SRL is sufficiently far enough away so that the cable can never contact the wire creating an electrocution hazard.
 - g) Consideration of obstacles present in the work area must include ALL locations that COULD be reached if the entire length of wire rope / web were extracted from the SRL. Obstacles that pose no threat when a worker is on a platform, for example, may be exposed to a dangerous situation should he climb downwards or moves laterally towards another work surface.
 - h) The wire rope / web used in SRL's should be protected from damage when passing over sharp edges or near objects where the cable / web could become lodged or pinched through the use of edge protectors that are not abrasive to the lifeline. When significant changes in angle are encountered, directional sheaves

- should be used or the SRL anchorage point should be relocated to a location that prevents contact with the sharp edge.
- i) Avoid installations where debris, contaminants, and other objects falling from above could damage the Skyloc[™] or its cable / web.
 - j) Extreme caution must also be exercised when considering the use of the Skyloc[™] SRL as a means of fall protection in areas where a user is working on a sloped surface such as a pitched roof or tank bottom, or on piles of loose material (such as grain or sand) that may shift or slide. If the user falls or begins to slide on such a surface, the Skyloc[™] lanyard may not be extracted fast enough for the device to lock-up (typically, lanyard must be extracted around 5-6ft/sec. for the unit to lock-up,) and arrest the sliding fall. The user might continue to slide over a roof edge, or into some other hazardous zone causing injury or death. The use of a travel restriction system or a work-positioning system may be more appropriate for such locations and should be considered first. Contact Reliance Engineering for help in selecting equipment for these applications.
- 5) Rescue and Evacuation - The user and employer must have a rescue plan in place, training in its use, and the means to implement it at hand. The employer must have the ability to perform a rescue quickly and safely. Do not plan to rely on others for rescue because prolonged suspension can cause bodily injury or death.

CARE OF THE SKYLOC[™] SRL

- A. Clean exterior by wiping away excess dirt, grease, or other materials that might interfere with operation of the unit. Dry hardware with a clean, dry cloth, and hang to air dry. Do not attempt to disassemble the unit. A buildup of dirt, solvents, paint, etc. on the lifeline may prevent the SRL from working properly, and in severe cases degrade the webbing to a point where it weakens and should be removed from service. More information on cleaning is available from RELIANCE. If you have questions concerning the condition of your SRL, or have any doubt about putting it into service contact RELIANCE.
- B. Store SRL's in a cool, dry, clean environment. Avoid areas where heat, oil, chemicals or their vapors may exist. Thoroughly inspect after extended storage. Good safety practice requires separate storage of unusable product from usable product.

INSPECTIONS

A. INSPECTION FREQUENCY

- 1) The SRL must be fully inspected by the user prior to each use.
- 2) A competent person other than the user must inspect the SRL thoroughly at least annually.

Note: Extreme working conditions (harsh environments that might degrade the webbing or corrode the hardware, prolonged use, etc.) may require increasing the frequency of inspections.

Record the results of each formal inspection in the inspection and maintenance log as described below.

B. INSPECTION PROCEDURE

- 1) Prior to each use, the worker must inspect the Skyloc™ Self-Retracting Lifeline for any physical damage, wear, corrosion, or malfunctioning parts. Verify that the load indicator is not visible by looking to see if the red slide bearing under the swivel eye on the anchor point or snaphook is exposed (Figures 11 & 12). Once the load indicator has been deployed, the SRL must be returned to a Reliance Industries approved repair facility for evaluation and recertification. Inspect load indicator webbing on SRL's with web lifelines. Remove from service if stitching is broken and/or "Remove From Service" label is visible (Figure 13).




Figure 11




Figure 12




Figure 13

- 2) The worker should also verify that conditions around the SRL location have not changed that may affect its' ability to arrest a fall, such as obstacles or equipment directly below the anchorage point which might create a swing fall.
- 3) Before every use, the worker should extract all of the cable / web and examine it for defects that would affect its overall strength. These defects would include but are not limited to weld strikes or burns, kinks, bends, "bird-caging", bends, bulge spots, outer diameter thinning, broken or snagged wire strands, broken or burned web or thread, etc. If a wire rope or webbing is showing evidence of any of these defects, the unit should be removed from service immediately until the wire rope or web is replaced and re-certified. The ferrules of the wire rope and stitching of the webbing by the snaphook should also be examined for cracks , deformation or broken and damaged stitching.
- 4) After the wire rope/web has been allowed to retract into the unit, the snaphook should be pulled sharply to verify proper lockup of the unit. If unit fails to lockup when pulled quickly, or if the cable fails to retract properly after lockup, the unit must be removed from service until repaired.

TRAINING

It is the responsibility of the employer to train all workers prior to using this system (per OSHA 1926.503 (a)(1)). The employer shall provide a training program for each employee who might be exposed to fall hazards. The program shall enable each employee to recognize the hazards of falling and shall train each employee in the procedures to be followed in order to minimize these hazards. The employer shall assure that, as necessary, each employee has been trained by a competent person qualified in the following areas:

- 1) OSHA regulations governing the use of horizontal lifelines.
- 2) Ability to recognize potential fall and workplace hazards.
- 3) Method of inspection of safety equipment.
- 4) Rescue procedures.
- 5) Installation and removal techniques.

Instructions for Use

RESCUE PLANNING

Prior to system use, a rescue plan must be prepared, the workers must be trained in its use, and the rescue equipment must be on hand to implement it in case of a fall. Typical rescue plans include (but are not limited to) the following items:

- 1) List of equipment that must be readily accessible in the event of an emergency and the names of those workers certified to use or operate that equipment.
- 2) Emergency contact phone numbers (ambulance, hospital, fire department...) and a means to contact them (cell phone, emergency radio).
- 3) List of employees on the site, and the specific tasks they will perform to effect the rescue.
- 4) The equipment that will be used to aid in the rescue of any worker should be attached to structural anchorages independent of those used for the personal fall arrest system. During installation of anchorages, tie-off and equipment attachment hard points should be attached, and also clearly marked in such a manner as to provide a means to rescue a worker in any position along the worksite.

SERVICING

A Qualified Person trained in the inspection and servicing of system components must carry out servicing of this system. The company's safety officer should maintain a record log of all servicing and inspection dates. The system and all components must be withdrawn from service if subjected to fall arrest forces. Those components may be returned to service only after being certified by a Qualified Person. Only original Reliance Industries equipment and replacement parts are approved for use in this system. Contact Reliance Industries Engineering with questions and when in need of assistance.

GUARDING AGAINST APPLICATION FAILURE

To avoid property damage, injury or death, the User must take reasonable steps to prevent "Application Failure". An application failure may be any unacceptable use, misuse, or application error on the part of the User or System Designer. Because each end user might use this product in a manner different from Reliance Industries testing platform, and because



the User might use this product in combination with other manufacturer's products in a manner not evaluated, contemplated, or tested by Reliance, the User or System Designer is ultimately responsible for verifying or validating the suitability and compatibility of this product for use in his application or system. Whenever questions regarding proper use or compatibility arise, please contact Reliance Engineering at (303) 424-8650.

WARNINGS AND LIMITATIONS

- 1) Proper care should always be taken to visually scan the work area prior to use. Remove any obstruction, debris, and other materials from, and beneath the work area that could cause injuries or interfere with the operation of this system. Be cautious of swing fall hazards if working anywhere but directly below the anchorage point of the SRL. Be aware of the movements of others using SRLs or shock-absorbing lanyards in close proximity, knowing that if the lines become crossed or tangled and a fall occurs, the sudden motion could pull others off balance and make rescue more difficult.
- 2) Do not release the wire rope/web when extended and allow it to retract back into the unit uncontrollably. Releasing the cable (web) and allowing it to reel itself in uncontrollably could cause damage to the Skyloc™. The wire rope (web) should be allowed to retract slowly into the unit under its' own power. If the unit is too far overhead to permit this, then a tagline should be attached to the snaphook to help control the line retraction.
- 3) In the course of use, do not allow the wire rope (web) to wrap around arms or legs, or become entangled in clothing or other items. In the event of a fall, they could cause injury, or prevent the Skyloc™ from functioning properly. Any Skyloc™ Self Retracting Lifeline that has the load indicator of the swivel snap showing (deployed) has seen a fall-arrest load and must be returned to Reliance Industries for evaluation, repair, and recertification. Units must not be reset in the field or allowed to be used until recertification has taken place.
- 4) Users should be familiar with pertinent regulations governing the use of this personal fall arrest system and its components. Only trained and competent personnel should install and supervise the use of this system.
- 5) Use only Reliance supplied or qualified compatible components.

Instructions for Use

6) Do not tie knots in the wire rope or webbing of the unit. Tying knots in wire rope (web) reduces the overall strength of the wire rope. Only connect to the Skyloc™ by using the Pelican™ swivel snap to connect to the dorsal (back) D-ring of a full-body harness. Do not cross lines with another worker. Should the lines become entangled, a fall by one worker could dislodge others. Plan and place SRLs to prevent workers from crossing safety lines.

LABELING

The illustrations on the following pages are representations of the actual labels that appear on Reliance Skyloc™ Self Retracting Lifelines.

All the information on the SRL Specifications Label is important for the safe use of this product, so the user should ensure that the label has not been removed and that the descriptions it contains match the task and environment in which the product is intended to be used. An inspection log is available on Page 26 of this manual. The unit should be inspected by a Competent Person at periodic intervals and at least monthly. As per these instructions, the unit should be tested for locking before each use.

PRODUCT LABELS



| MAXIMUM WORKING LOAD (INCL. TOOLS): 1 PERSON (50-LB. MIN., 310-LB. MAX.) MAX. ARREST DIST.: 3.5-FT. (2-IN.) | | | | | | |
|---|--------------------------------|------------|----------|----------------|-------------|-----------|
| PART # | SRL LINE MATERIAL | MIN. BREAK | SNAPHOOK | EXTERNAL SHOCK | WORK LENGTH | ANSI Z359 |
| 4010 | 3/16-IN. WIRE ROPE, GALV. | 3,400-LB. | 3005 | YES | 10-FT. | YES |
| 4011 | 1-IN. WIRE X, 0.50-IN. DYWIDAG | 5,000-LB. | 3005 | YES | 11-FT. | YES |
| 4012 | 1-IN. WIRE X, 0.50-IN. DYWIDAG | 5,000-LB. | 3014 | YES | 11-FT. | NO |

| MAXIMUM WORKING LOAD (INCL. TOOLS): 1 PERSON (50-LB. MIN., 310-LB. MAX.) MAX. ARREST DIST.: 3.5-FT. (2-IN.) | | | | | | |
|---|--------------------------------|------------|----------|----------------|-------------|-----------|
| PART # | SRL LINE MATERIAL | MIN. BREAK | SNAPHOOK | EXTERNAL SHOCK | WORK LENGTH | ANSI Z359 |
| 4006 | 3/16-IN. WIRE ROPE, GALV. | 3,400-LB. | 3005 | NO | 6-FT. | YES |
| 4007 | 1-IN. WIRE X, 0.50-IN. DYWIDAG | 5,000-LB. | 3005 | NO | 7-FT. | YES |
| 4008 | 1-IN. WIRE X, 0.50-IN. DYWIDAG | 5,000-LB. | 3011 | NO | 7-FT. | YES |
| 4009 | 1-IN. WIRE X, 0.50-IN. DYWIDAG | 5,000-LB. | 3014 | NO | 7-FT. | NO |

4006, 4007, 4008, 4009, 4011

PRODUCT LABELS

Model # 4020

MAXIMUM ARREST
FORCE (MAF): 900-LB.
SRL LINE MATERIAL: 1-IN.
POLYESTER WEAVING

MAXIMUM WORKING
LOAD: 1 PERSON
90-LB. MIN. -
310-LB. MAX.
20-FT. WORKING
LENGTH.

WARNING

READ USER
MANUAL AND
LABELS BEFORE
USE. FAILURE TO
OBSERVE INSTRU-
CTIONS COULD
RESULT IN INJURY
OR DEATH. INSPECT
SRL BEFORE EACH
USE. IF THIS
PRODUCT HAS BEEN
SUBJECTED TO A FALL ARREST
LOAD, RETURN TO AUTHORIZED SERVICE
CENTER FOR RECERTIFICATION. THIS
RETRACTABLE REQUIRES A MINIMUM ACTIVATION
SPEED. DO NOT USE WHERE SLIDING MOTION WOULD NOT
REACH ACTIVATION SPEED. DO NOT INSTALL OR USE NEAR
ELECTRICAL HAZARDS OR ENERGIZED EQUIPMENT.
REDUCE SWING FALL HAZARDS BY KEEPING
WORKERS DIRECTLY BENEATH DEVICE

Complies with ANSI Z359.1 (07)

Model # 4015

MAXIMUM ARREST
FORCE (MAF): 900-LB.
SRL LINE MATERIAL:
3/16-IN. WIRE ROPE.

MAXIMUM WORKING
LOAD: 1 PERSON
90-LB. MIN. -
310-LB. MAX.
18-FT. WORKING
LENGTH.

WARNING

DO NOT USE IN
PLACES WHERE
THERE IS A POSSI-
BILITY OF SLOW
ENGULFMENT
FROM SHIFTING
CONTENTS.
ALWAYS INSPECT
ATTACHMENT OF
SNAP TO BE SURE IT
CANNOT LOAD SNAP GATE
IN A MANNER THAT COULD CREATE
ACCIDENTAL DISENGAGEMENT. NEVER
ALLOW THE LANYARD TO RETRACT
UNCONTROLLABLELY. USE A TAG LINE TO ALLOW
SLOW RETRACTION OF LINE INTO HOUSING. DO NOT ALLOW
WIRE ROPE TO COME INTO CONTACT WITH ELECTRICAL
EQUIPMENT OR SHARP SURFACES THAT COULD DAMAGE
CABLE. DO NOT CLIMB ABOVE THE ANCHORAGE.
ALWAYS CONNECT SRL SNAPHOOK TO BACK DORSAL
D-RING OF HARNESS.

| | | | | | | | | | | | | |
|-------|------|------|------|------|------|------|----|----|----|----|----|----|
| MONTH | 01 | 02 | 03 | 04 | 05 | 06 | 07 | 08 | 09 | 10 | 11 | 12 |
| YEAR | 2009 | 2010 | 2011 | 2012 | 2013 | 2014 | | | | | | |

MEETS OR EXCEEDS APPLICABLE OSHA REGULATIONS MADE IN USA

Skyloc
SELF-RETRACTING LANYARD
RELIANCE INDUSTRIES, LLC

WARNING

DO NOT USE FOR
FALL ARREST OF
MORE THAN ONE
PERSON.
AVOID
PROLONGED
EXPOSURE TO
CAUSTIC OR
CORROSIVE
ENVIRONMENTS.
STORE SRL
WITH LINE
FULLY
RETRACTED.
DO NOT PERMIT
CABLE OR WEB
TO WRAP AROUND
BODY OR LIMBS.

WARNING

DO NOT TIE-OFF OR
OTHERWISE
PREVENT LINE
FROM RE-
TRACTING WHEN
IN USE.
DO NOT
PERMIT SLACK
TO FORM IN
LINE.
ATTACH SRL TO
ANCHORAGE
APPROVED BY A
QUALIFIED
PERSON OR
ENGINEER.
MOVE CAUTIOUSLY
TO PREVENT LOSS OF
BALANCE SHOULD UNIT LOCK UP.

INSTRUCTIONS FOR USE:

1. ATTACH SRL TO SUITABLE ANCHORAGE CERTIFIED BY A QUALIFIED PERSON OR ENGINEER.
2. INSPECT SRL FOR MISSING PARTS OR VISIBLE DEFECTS. REMOVE FROM SERVICE IF ANY ARE FOUND.
3. GIVE LINE A QUICK, SHARP TUG TO VERIFY LOCKUP. REMOVE FROM SERVICE IF UNIT FAILS TO LOCK OR WILL NOT UNLOCK.
4. VERIFY LOAD INDICATOR IS INTACT. IF DEPLOYED, REMOVE UNIT FROM SERVICE.
5. ATTACH SNAPHOOK TO BACK D-RING OF HARNESS.


RELIANCE INDUSTRIES, LLC
2802 East X Street, Deer Park, TX 77536
281-930-8000 / www.reisafe.com

Instructions for Use

PRODUCT LABELS

SKYLOC[®]
SELF-RETRACTING LANYARD

MADE IN USA



RELIANCE
fall protection

Houston, TX
 Ph. 888-362-2826
 Fax (281)930-8666

WARNING:

- If this product has been subjected to a fall arrest or "NEXT INSPECTION DATE" has been passed, return to authorized service center for re-certification.
- Do not climb above the anchorage.
- This retractable requires a minimum activation speed to engage. Do not use where sliding motion, such as on a low pitched roof, would not allow the worker to reach activation speed.
- Do not use in silos where there is a possibility of slow engulfment from shifting contents.
- Never allow the cable to retract uncontrollably; use a tag line to allow slow retraction of cable into housing.
- Do not install or use near electrical hazards or energized equipment.
- Reduce swing fall hazards by keeping workers directly beneath device.
- Avoid prolonged use in caustic or corrosive environments.

WARNING:

- The anchorage point that this device is attached to must be capable of supporting 5000-lb. (22.2 kN).
- Always inspect attachment of snap to be sure it cannot load snap gate in a manner that could create accidental disengagement.

Instructions for use:

1. The user must understand and follow manufacturers' instructions included with this product at the time of shipment. Read and heed all labels and warnings.
2. All workers must be trained prior to use.
3. Use only for personal fall arrest.
4. Inspect before each use. Consult owners manual for inspection procedures.
5. Inspect locking action prior to use by pulling sharply on lanyard.
6. Units subjected to fall arrest or which do not pass inspection or are due for service must be immediately removed from use and returned to the Manufacturer for inspection, repair, and re-certification.

| DESCRIPTION | | | | |
|----------------|------|------|----|------|
| TYPE | P/N | GALV | SS | P/N |
| 130-ft. Skyloc | 4130 | | | 4131 |
| 100-ft. Skyloc | 4100 | | | 4101 |
| 50-ft. Skyloc | 4050 | | | 4051 |
| 30-ft. Skyloc | 4030 | | | 4031 |
| Custom | | | | |

MAXIMUM WORKING LOAD: 1 person; 90-lb. min., 310-lb. max.
 MAXIMUM ARREST FORCE: 900-lb. (4 kN)
 MAXIMUM ARREST DISTANCE: 42-in. (1.06 m)

DATE OF MANUFACTURE:

| | | | | | | | | | | | | |
|-------|----|----|----|----|----|----|---|---|---|----|----|----|
| MONTH | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 |
| YEAR | 07 | 08 | 09 | 10 | 11 | 12 | | | | | | |

Manufactured by Reliance Industries, LLC

Meets or exceeds ANSI A10.14 & Z359.1, & all applicable OSHA regulations.

4030, 4050, 4051, 4075, 4100, 4101, 4120, 4121, 4130, 4131

EQUIPMENT RECORD

| | |
|-------------------|----------------------|
| PART NUMBER | <input type="text"/> |
| SERIAL NUMBER | <input type="text"/> |
| DATE MANUFACTURED | <input type="text"/> |
| PURCHASE DATE | <input type="text"/> |
| ASSIGNED TO | <input type="text"/> |

INSPECTION RECORD

| DATE | INSPECTOR | PASS/FAIL |
|------|-----------|-----------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

SPECIFICATIONS

SKYLOC™ SRL'S

Certified to meet the current ANSI Z359.1(2007) and OSHA regulations for the Self Retracting Lifeline component of a complete personal fall arrest system. Lanyard webbing certified minimum 9000 lb. (4082kg) breaking strength, all hardware certified to 5000 lb. (22kN) breaking strength, 100 percent proof tested to 3600 lbs. (16.5kN).

Individually serial number and date of manufacture are on product label.

Made in Texas, USA

Instructions for Use

These Instructions Apply to the Following Part Numbers :

4006
4007
4008
4009
4011
4015
4020
4030
4031
4050
4051
4075
4100
4101
4130
4131

Warranty

Products manufactured by Reliance Industries LLC are warranted against factory defects in workmanship and materials for a period of two years from date of purchase by the owner (end user) or for a period of one year from date first used, provided that this period shall not exceed two years from date of shipment to distributor. Upon notice of product defect or fault, Reliance Industries LLC will promptly repair or replace all defective items. Reliance Industries LLC reserves the right to elect to have any defective item returned to its manufacturing plant, authorized service center or distributor for inspection before making a repair or replacement. This warranty does not cover equipment damages or defects resulting from abuse, damage in transit, or other damage beyond the control of Reliance Industries. This warranty applies only to the original purchaser and is the only one applicable to our products and services, and is in lieu of all other warranties, expressed or implied. When products offered by Reliance Industries LLC are manufactured by a third party. Original equipment manufacturer (OEM) warranty shall apply and may be outside the control of Reliance Industries LLC.



Reliance Industries
P.O. Box 2046
Deer Park, TX 77536
Phone : 281-930-8000
Toll Free : 888-362-2826
Fax : 281-930-8666
www.relsafe.com